

Item No.: LM9677

IMS displacement measurement module

Displacement measurement system for use with the IMS System with connecting lead and attaching mount.

- Optical sensor for incremental displacement measurement
- Switching function: PNP normally open switch
- Connectors: M12 angled plugs, 2-m lead
- Operating voltage: 24 V

